



## Blutekonnect - Quick Start Guide #

### [Power on]

Press and hold the <POWER> button until both the Red and Blue LED lights are on, For pairing with a phone for the first time you will need to hold the <POWER> button down for 8 seconds, or until the Blue and Red LED lights flash independently.

### [Power off]

Press and hold the <POWER> button until all LED is bright together, Later all LED was killed and already power off completely.

### [Pairing with Mobile] PIN CODE: 0000

With the Blutekonnect in the power off state press and hold the <POWER> button, hold until the Red & Blue lights flash independently.

Turn on the mobile phones Bluetooth and search. Once the Phone has found KBxxxx, pair and enter code: 0000. After this you can rename the device to the name of your choosing.

(Note: So long as Bluetooth Hands free Profile & Bluetooth Audio Gateway Profile can be supported)

### [Cancel pairing with Mobile]

Turn off Bluetooth on the Mobile Phone, or hold down the <POWER> button for 5 seconds.

### [Search the new earphone and pairing] PIN CODE: 0000

Press and hold <POWER> + <INTERCOM> button under the power off state, power on and hold it until red&blue light flashes mutually continuously.

(Note: Will only pair with supporting the earphone of bluetooth Headset Profile)

### [Raise volume]

Tap <VOL +> button.

### [Reduce volume]

Tap <VOL-> button.

### [Restore to factory settings]

Under no connection state, press <POWER> + <INTERCOM> + <TALK> + <VOL-> at the same time.

### [Connect to the mobile phone]

Before have connect mobile and want to connect mobile again, short to press <TALK> button

can initial connect last Mobile.



**[Disconnect from the mobile phone]**

Press and hold <POWER> button until you hear a beep.

**[Voice dial] (Phone must support Voice Dial function)**

Hold <TALK> button for 2 seconds while connected to mobile phone.

**[Answer a call]**

When a call is incoming press the <TALK> button.

**[Reject a call]**

When a call is incoming, Press and hold <TALK> button until you hear a beep.

**[End call]**

Press <TALK> button.

**[Last number redial ]**

Press and hold <VOL-> button until you hear a beep.

**[Answer an incoming call ]**

During current call, press the <TALK> button to answer an incoming call.

**[Reject an incoming call ]**

During current call press and hold the <TALK> button until you hear a beep.

**[Keep Current call on hold and answer incoming call]**

Press and hold the <VOL+> button until you hear a beep.

**[Three way calling]**

Press and hold the <VOL-> button while in a call until you hear a beep.

**[Reconnect to first call]**

Press the <TALK> button to finish the current call and reconnect to call on hold.

**[Finish all calls]**

Press and hold the <TALK> button to end all calls.

**[Pair two helmets for intercom]**

On helmet desired to be master press and hold power button and intercom button for 8 seconds. On helmet desired to be slave press and hold power button for 8 seconds. The devices will automatically pair, you will hear a beep that confirms pairing. After you hear the beep on either helmet press the intercom button to make the call to the paired helmet. The device will automatically connect.

**[Pairing for intercom after initial intercom pairing]**

Press and hold power button and intercom button on master helmet until you hear the first beep. On the slave helmet press and hold the power button until you hear the first beep. You will hear a beep which means the helmets are connected. Either helmet can then press the intercom button to establish connection between the helmets



### **[Pairing Phone and intercom simultaneously]**

Make sure you have paired with both devices at least one time so the helmet can memorize the devices. Have both helmets in the off mode. Turn on your Bluetooth on your Mobile phone. On the master helmet press and hold the power and intercom button until you hear a beep. On the slave helmet press and hold the power button until you hear a beep. The helmet will first connect with the phone and also connected to the intercom helmet as a secondary. To initiate an intercom call press the intercom button on either helmet. To pause the connection press the intercom button again and the Mobile Phone will be reconnected.

### **[Pause Intercom]**

Press the <INTERCOM> button to pause the intercom connection. Press it again to re-initiate the intercom connection

### **[End Intercom]**

Press and hold the <INTERCOM> button until you hear a beep,

### **Changing Tracks**

#### **[Previous Track]**

Press and hold the <VOL+> button until you hear a beep.

#### **[Next Track]**

Press and hold the <VOL-> button until you hear a beep.

### **The LED light state**

#### **[Pairing state ]**

Red&blue lights flash independently.

#### **[Request connect state ]**

Both Red and Blue lights are on with one flashing (Blue light on while Red light flashes, Red light on while Blue light flashes)

#### **[Mobile Phone connected ]**

Blue light flashes

(When the Red light flashes it indicates low battery)

#### **[Intercom conversing state]**

Blue Light flashes once then twice rapidly

(When the red light flashes it indicates low battery)

#### **[Idle state]**

Blue Light flashes

(When the Red light flashes it indicates low battery)

